Features

- Basic monitoring for power supply output and health
- Plug-in Module for the FieldConnex Power Hub
- Plug and play no engineering required
- · For online monitoring
- For FOUNDATION Fieldbus H1 and PROFIBUS PA
- Installation in Zone 2/Class I, Div. 2
- · System state and fault indication via LEDs

Function

Designed as a plug-in module for the FieldConnex® Power Hub, the Basic Diagnostic Module HD2-DM-B provides basic system diagnostics. It checks for proper operation of bulk power supplies and monitors the connected trunks for overload or short-circuit conditions. All Power Hub modules are checked for proper function. On redundant power modules it indicates missmatching pairs.

The module indicates a fault condition via voltage-free contact. It provides monitoring "plug-and-play" without additional engineering. LED signals indicate a fault for easy detection.



Assembly














Connection




Zone 2/Div. 2

| General specifications | |
|---|---|
| Design / Mounting | Motherboard based |
| Supply | |
| Rated voltage U _r | 19.2 35 V |
| Rated current I _r | 20 mA |
| Power dissipation | max. 0.5 W |
| Indicators/operating means | IIIdx. U.J YY |
| LED PRI PWR | green: on, primary bulk power supply connected |
| LED SEC PWR | green: on, secondary bulk power supply connected |
| LED SECTION LED ERR | red: 2 Hz flashing, power supply fault (short-circuit, undervoltage), redundancy fault |
| | |
| Fault signal Galvanic isolation | VFC alarm 1 A, 50 V DC, normally closed |
| | functional inculation ago to IEC 60102 vated inculation valtage EQ.V |
| Fieldbus segment/Fieldbus segment | functional insulation acc. to IEC 62103, rated insulation voltage 50 V _{eff} |
| Directive conformity | |
| Electromagnetic compatibility | FN 04000 4 0040 |
| Directive 2014/30/EU | EN 61326-1:2013 |
| Standard conformity | NE or corr |
| Electromagnetic compatibility | NE 21:2011 |
| Degree of protection | IEC 60529 |
| Shock resistance | EN 60068-2-27 |
| Vibration resistance | EN 60068-2-6 |
| Ambient conditions | |
| Ambient temperature | -40 70 °C (-40 158 °F) |
| Storage temperature | -40 85 °C (-40 185 °F) |
| Relative humidity | < 95 % non-condensing |
| Shock resistance | 15 g 11 ms |
| Vibration resistance | 1 g , 10 150 Hz |
| Pollution degree | max. 2, according to IEC 60664 |
| Corrosion resistance | acc. to ISA-S71.04-1985, severity level G3 |
| Mechanical specifications | |
| Connection type | motherboard specific |
| Core cross-section | motherboard specific |
| Housing material | Polycarbonate |
| Housing width | 18 mm |
| Housing height | 106 mm |
| Housing depth | 128 mm |
| Degree of protection | IP20 |
| Mass | approx. 70 g |
| Mounting | motherboard mounting |
| Data for application in connection with hazardous areas | |
| Certificate | TÜV 04 ATEX 2500 X |
| | (€x) II 3 G Ex nA nC IIC T4 Gc |
| Marking | W II 3 G EXTINITIO IIC 14 GC |
| Directive conformity | EN 60070 0:2010 EN 60070 11:2012 EN 60070 15:2010 |
| Directive 2014/34/EU | EN 60079-0:2012, EN 60079-11:2012, EN 60079-15:2010 |
| International approvals | 0-0 0004010 0-0 00040100 |
| FM approval | CoC 3024816, CoC 3024816C |
| Approved for | Class I, Division 2, Groups A, B, C, D, T4 / Class I, Zone 2, AEx/Ex nC IIC T4 |
| IECEx approval | IECEX TUN 13.0038X |
| Approved for | Ex nA nC IIC T4 Gc |
| Certificates and approvals | D10/4 4400 |
| Marine approval | DNV A-14038 |
| General information | |
| Supplementary information | Statement of Conformity, Declaration of Conformity, Attestation of Conformity and instructions have to be observed where applicable. For information see www.pepperl-fuchs.com. |



Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com

Dimensions



Description:

- Power Supply Modules, see separate data sheets
- **Diagnostics Module**
- Connections for fieldbus trunk, terminator switch
- Screening/earthing kit for trunk cables shield, optional accessory
- Mounting slot for DIN rail
- 6 Motherboard, see separate data sheets
- Connections for alarm, voltage free contact and diagnostics bus
- 8 Connections for redundant host
- Connections for redundant bulk power supply
- 10 Plug connections to Motherboard
- 11 State and fault indication LEDs

Installation note

see manual

Accessories

see system data sheet